

AD-A132 605



**CHEMICAL  
SYSTEMS  
LABORATORY**

US Army Armament Research and Development Command  
Aberdeen Proving Ground, Maryland 21010

AD

(R)

SPECIAL PUBLICATION ARCSL-SP-83006

**ESTIMATION OF PARAMETERS FOR TRUNCATED DISTRIBUTIONS**


by

Ronald O. Pennsyle

Systems Analysis Branch  
Systems Development Division

20030108178

June 1983



DMC FILE COPY

Approved for public release; distribution unlimited.

83 09 19 100

## **REPRODUCTION QUALITY NOTICE**

**This document is the best quality available. The copy furnished to DTIC contained pages that may have the following quality problems:**

- **Pages smaller or larger than normal.**
- **Pages with background color or light colored printing.**
- **Pages with small type or poor printing; and or**
- **Pages with continuous tone material or color photographs.**

**Due to various output media available these conditions may or may not cause poor legibility in the microfiche or hardcopy output you receive.**



**If this block is checked, the copy furnished to DTIC contained pages with color printing, that when reproduced in Black and White, may change detail of the original copy.**

**Disclaimer**

The information in this report is not to be construed as an official Department of the Army position, unless so designated by other authorized documents.

**Disposition**

Destroy this report when no longer needed. Do not return to the originator.

## UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

REPORT DOCUMENTATION PAGE		READ INSTRUCTIONS BEFORE COMPLETING FORM
1. REPORT NUMBER ARCSL SP-83006	2. GOVT ACCESSION NO. <i>AD-4132 605</i>	3. RECIPIENT'S CATALOG NUMBER
4. TITLE (and Subtitle) ESTIMATION OF PARAMETERS FOR TRUNCATED DISTRIBUTIONS	5. TYPE OF REPORT & PERIOD COVERED Special Publication 1-27 October 1980	
7. AUTHOR(s) Ronald O. Pennsyle	6. PERFORMING ORG. REPORT NUMBER	
9. PERFORMING ORGANIZATION NAME AND ADDRESS Commander, Chemical Systems Laboratory ATTN: DRDAR-CLY-A Aberdeen Proving Ground, Maryland 21010	10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS Project 1L162706A554 Technical Area 4-C	
11. CONTROLLING OFFICE NAME AND ADDRESS Commander, Chemical Systems Laboratory ATTN: DRDAR-CLJ-IR Aberdeen Proving Ground, Maryland 21010	12. REPORT DATE June 1983	
14. MONITORING AGENCY NAME & ADDRESS (if different from Controlling Office)	13. NUMBER OF PAGES 22	
	15. SECURITY CLASS. (of this report) UNCLASSIFIED	
	15a. DECLASSIFICATION/DOWNGRADING SCHEDULE NA	
16. DISTRIBUTION STATEMENT (of this Report)  Approved for public release, distribution unlimited.		
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)		
18. SUPPLEMENTARY NOTES  This report supersedes ARCSL-TM-81001 dated January 1981.		
19. KEY WORDS (Continue on reverse side if necessary and identify by block number) Particle size Lognormal distribution Computer program		
20. ABSTRACT (Continue on reverse side if necessary and identify by block number) Truncated distributions are frequently encountered in the experimental determination of size distributions of aerosols, dusts, and other collections of small particles. A technique for determining maximum likelihood estimates of the geometric mean and standard deviation of a truncated lognormal distribution has been found in the published literature and implemented in a BASIC computer program. This special publication describes the method and the computer program.		


## PREFACE

The work described herein originated in the Methodology Group of Systems Analysis Branch, Systems Development Division. It was authorized by Project 1L162706A554, Smoke/Obscurants, was performed from 1 to 27 October 1980, and is part of the Chemical Systems Laboratory's (CSL) support of Technical Area 4-C, Smoke Technology, to develop methodology for operational assessment.

The use of trade names in this report does not constitute an official endorsement or approval of the use of such commercial hardware or software. This report may not be cited for advertisement purposes.

Reproduction of this document in whole or in part is prohibited except with permission of the Commander, Chemical Systems Laboratory, ATTN: DRDAR-CLJ-IR, Aberdeen Proving Ground, Maryland 21010. However, the Defense Technical Information Center and the National Technical Information Service are authorized to reproduce the document for US government purposes.

This report has been approved for release to the public.



BLANK

## CONTENTS

	Page
1. INTRODUCTION.....	7
2. THE PROBLEM.....	7
3. A SOLUTION.....	8
4. ILLUSTRATIVE EXAMPLE.....	10
5. SUMMARY.....	10
 APPENDIX	
A Computer Program for Estimating the Parameters of a Truncated Lognormal Distribution.....	11
DISTRIBUTION LIST.....	17

BLANK

## ESTIMATION OF PARAMETERS FOR TRUNCATED DISTRIBUTIONS

### 1. INTRODUCTION

The analysis of chemical warfare systems involves the use of distributions of droplet, particle, spot, and fragment sizes. Many field and laboratory tests are conducted to obtain data for the determination of such distributions. As a practical matter, the experimenter usually assumes the data are best characterized by a lognormal distribution, which is equivalent to assuming that the logarithm of the sizes is normally distributed. Then he proceeds to perform the routine calculations for the mean and standard deviation of the data and reports the results. If his experimental measurements span the range of possible sizes and the number of observations is sufficiently large, this procedure leads to acceptable results. However, many measuring devices are limited to a specific operating range, particularly on the low end, beyond which no data are obtainable. Since most experimenters are familiar with procedures for dealing with the effects of sample size on their estimates, this topic is not addressed further. On the other hand, many experimenters fail to recognize or consider properly the effect of such missing data. The purpose of this report is to describe the problem and present a method for determining the best estimates of the parameters of a truncated lognormal distribution.

### 2. THE PROBLEM

For the present purpose, it is assumed that a lognormal distribution of sizes of spherical liquid drops is adequate to represent the data collected in an experiment which counted the number of drops in each of a finite set of size intervals. The mathematical expression for the probability density function of the lognormal distribution is

$$f(d) = (d \ln \sigma_g \sqrt{2\pi})^{-1} \exp \left[ -\frac{1}{2} \left( \frac{\ln d - \ln d_N}{\ln \sigma_g} \right)^2 \right]$$

where

$d$  = diameter of a drop  
 $d_N$  = number median diameter (geometric mean)  
 $\sigma_g$  = geometric standard deviation of the diameters

The objective of the experimenter is to obtain the best estimates of  $d_N$  and  $\sigma_g$ , or possibly the mass median diameter  $d_M$ , which is related to  $d_N$  by the expression

$$\ln d_M = \ln d_N + 3 \ln^2 \sigma_g \quad (2)$$

Suppose the experimental data obtained consist of the number  $n_i$  of drops in the  $i$ -th size interval such that  $d_{i-1} \leq d < d_i$  for  $i=1, 2, \dots, k$  and  $d_0 > 0$ . No information is available for any  $d < d_0$ . If this truncation of the distribution at  $d_0$  is not considered, the results reported will be

$$\hat{d}_N = \exp \left\{ \frac{\sum_{i=1}^k n_i \ln \left[ \frac{1}{2} (d_{i-1} + d_i) \right]}{\sum_{i=1}^k n_i} \right\} \quad (3)$$

and

$$\hat{\sigma}_g = \exp \left\{ \left( \frac{\sum_{i=1}^k n_i \ln^2 \left[ (d_{i-1} + d_i) / (2d_N) \right]}{\sum_{i=1}^k n_i - 1} \right)^{1/2} \right\} \quad (4)$$

where the estimates  $\hat{d}_N$  and  $\hat{\sigma}_g$  may be far from the best estimates. Depending on the degree of truncation, the estimate of  $d_N$  will be too high, while that of  $\sigma_g$  will be too low by an undetermined amount.

### 3. A SOLUTION

In 1908, Pearson and Lee\* reported an algorithm for obtaining maximum likelihood estimates of the mean and standard deviation of a singly truncated normal distribution. Maximum likelihood estimates may be defined as those which describe the distribution of a random variable most likely to produce the set of observations of a random experiment. In many instances, these estimates are unbiased and of minimum variance; but, these properties, while most desirable, are not guaranteed.

The Pearson-Lee method consists of solving the equations derived by equating the first and second sample and population moments about the point of truncation. If the point of truncation is not known precisely, it is recommended that a point slightly less than the lowest observed size be used. The equations to be solved are

$$\sigma = \left[ \frac{z(x)}{1-\phi(x)} - x \right]^{-1} \bar{u} \quad (5)$$

---

\* Pearson, Karl, and Lee, Alice. On the Generalized Probable Error in Multiple Normal Correlation, Biometrika 6, 59-68, (1908).

and

$$\frac{\hat{\sigma}}{\bar{u}} \left( \frac{\hat{\sigma}}{\bar{u}} - x \right) = \frac{\sum_{i=1}^k n_i u_i^2}{\bar{u}^2} \quad (6)$$

$$u = u^l - u_o^l \quad (7)$$

where  $u^l$  = original random variable

$u_o^l$  = truncation point ( $u_o^l \leq u^l$ )

$$\bar{u} = \frac{\sum_{i=1}^k n_i u_i}{\sum_{i=1}^k n_i} \quad (8)$$

$$x = \frac{u_o^l - \hat{m}}{\hat{\sigma}}, \text{ a standard deviate} \quad (9)$$

where  $\hat{m}$  = mean of the normal distribution (estimated)

$\hat{\sigma}$  = estimated normal standard distribution

$$z(x) = (\sqrt{2\pi})^{-1} \exp(-x^2/2) \quad (10)$$

$$\phi(x) = \int_{-\infty}^x z(t) dt \quad (11)$$

By solving equation (5) for  $\hat{\sigma}/\bar{u}$  and substituting in equation (6), a nonlinear equation in  $x$  arises. Once  $x$  is determined by some means,  $\hat{\sigma}$  can be obtained from equation (5) and  $\hat{m}$  from solving equation (9). Cohen and Woodward\* have published tables for solution of the equations, and we have prepared a computer program in BASIC (see the Appendix) for numerical solution.

In terms of the lognormal distribution of our problem

$u^l = \ln d$ ,

$u_o^l = \ln d_o$ ,

$u = \ln(d/d_o)$ ,

$\hat{\sigma}_g = \exp(\hat{\sigma})$ , and

$d_N = \exp(\hat{m})$

\* Cohen, A.C., and Woodward, John. Tables of Pearson-Lee-Fisher Functions of Singly Truncated Normal Distribution. Biometrics 9, 489-497 (1953).

#### 4. ILLUSTRATIVE EXAMPLE

An aerosol sample injected into a particle counter produced the data shown in table 1. The smallest particle resolved was 0.15  $\mu\text{m}$  in diameter. One can see that the data are truncated just below the mode of the distribution, this implies that neglect of the truncation could produce a significant error. In fact, the estimates obtained by the blind application of routine formulas are  $\hat{d}_N = 0.200$  and  $\hat{\sigma}_g = 1.20$ . If we apply the Pearson-Lee algorithm as implemented in the computer program, we get  $\hat{d}_N = 0.186$  and  $\hat{\sigma}_g = 1.26$ , and note that the differences in the estimates are in the expected directions.

Table 1. Experimental Observations

<u>Point No.</u>	<u>Size Range</u>	<u>Count</u>	<u>Point No.</u>	<u>Size Range</u>	<u>Count</u>
1	0.15 - 0.16	375	16	0.305 - 0.330	21
2	0.16 - 0.17	408	17	0.330 - 0.355	10
3	0.17 - 0.18	428	18	0.355 - 0.380	6
4	0.18 - 0.19	384	19	0.380 - 0.405	3
5	0.19 - 0.20	379	20	0.405 - 0.430	2
6	0.20 - 0.21	333	21	0.430 - 0.455	1
7	0.21 - 0.22	279	22	0.455 - 0.480	0
8	0.22 - 0.23	207	23	0.480 - 0.505	1
9	0.23 - 0.24	203	24	0.505 - 0.530	0
10	0.24 - 0.25	139	25	0.530 - 0.555	0
11	0.25 - 0.26	176	26	0.555 - 0.580	0
12	0.26 - 0.27	113	27	0.580 - 0.605	0
13	0.27 - 0.28	75			
14	0.28 - 0.29	65			
15	0.29 - 0.30	51			

#### 5. SUMMARY

A method has been found and implemented to obtain estimates of the parameters of truncated normal and lognormal distributions. Emphasis is placed on the importance of recognizing the truncation of data by measuring devices and on the ease with which the problem can be solved.

## APPENDIX

### A Computer Program for Estimating the Parameters of a Truncated Lognormal Distribution

A computer program has been written to implement the Pearson-Lee method of estimating the parameters of a normal distribution and to apply the technique to data from a lognormal distribution. The program is written in BASIC for the Tektronix (TEK) 4051 Graphics Calculator. The interactive mode is used to prompt the demand terminal user for the proper input sequence. Because the TEK 4051 has an internal tape unit, provision is made for data storage and retrieval from unit 33. Statements may be removed from unit 33 and used with other terminals or host computers. The program also calculates estimates of the parameters using a method by Cohen which uses the third moments about the truncation point. Use of third moments is believed to introduce inaccuracies which become apparent in the large deviations from the Pearson-Lee maximum likelihood estimates. A listing of the program appears at the end of the appendix.

Two comments are needed to guide the program user:

1. The test identification can be a string of 72 characters.
2. The size requested should be the midpoint of the size range represented.

```

1 GO TO 100
14 GOSUB 849
15 PRINT X,2,P,H,H1,F,F1
16 GO TO 1100
18 GO TO 1030
12 GO TO 110
16 GO TO 730
100 INIT
110 PAGE
120 PRINT "ENTER NO. OF OBSERVATIONS : ";
130 INPUT N0
140 PRINT "ENTER LOWER BOUND OF DATA : ";
150 INPUT D0
160 PRINT "ENTER TEST IDENTIFICATION"
170 INPUT A$
180 RESTORE 200
190 READ N, S1, S2, S3, S4, S5, R9
200 DATA 0, 0, 0, 0, 0, 0, 0
210 IF N0=0 THEN 390
220 PRINT "ENTER INPUT FILE NO. (0 FOR KEYBOARD, -FILE FOR SAVE): ";
230 INPUT F2
240 IF F2=0 THEN 260
250 FIND ABS(F2)
260 PRINT "ENTER DATA PAIRS, (SIZE, FREQ.) : "
270 DIM D2(N0), M2(N0)
280 N0=N0
290 FOR I=1 TO N0
300 IF F2<=0 THEN 330
310 INPUT @33:D2(I), M2(I)
320 GO TO 360
330 INPUT D2(I), M2(I)
340 IF F2=0 THEN 360
350 PRINT @33:D2(I), M2(I)
360 NEXT I

```

```

370 PAGE
375 PRINT AS
380 PRINT "POINT NO.", "SIZE RANGE", "COUNT"
389 FOR I=1 TO N0
395 IF R9<1 THEN 430
400 FOR J=1 TO R9
410 IF I=M3(J) THEN 510
420 NEXT J
430 N=N+M2(I)
440 S1=S1+M2(I)*LOG(D2(I))
450 S2=S2+M2(I)*LOG(D2(I))12
460 S3=S3+M2(I)*LOG(D2(I))20
470 S4=S4+M2(I)*LOG(D2(I))32
480 S5=S5+M2(I)*LOG(D2(I))48
490 IF N0=0 THEN 510
500 PRINT I,D2(I),M2(I)
510 NEXT I
520 D1=EXP(S1/N)
530 S=EXP(SQR((S2-N)*LOG(D1))12)/(N-1))
540 PRINT "STATISTICS OF RAW DATA"
550 PRINT "STATISTICS OF RAW DATA"
560 PRINT "GEOMETRIC MEAN = ";D1
570 PRINT "GEOMETRIC STD. DEV. = ";S
580 PRINT "GEOMETRIC STD. DEV. = ";S
590 PRINT X=(LOG(D0)-LOG(D1))/LOG(S)
600 RESTORE 640
610 C=N*S4/S312
620 READ G,E
630 DATA 30,1.0E-8
640 GOSUB 950
650 GOSUB 840
660 S9=EXP(S3/H12)
670 D9=EXP(LOG(D0)-X12LOG(S9))
680 PRINT "STATISTICS USING PEARSON-LEE METHOD"

```

```

700 PRINT "ADJUSTED GEOMETRIC MEAN = ";D9
710 PRINT "ADJUSTED GEOM. STD. DEV. = ";S9
720 P1=S3/N
730 P2=S4/N
740 P3=S5/N
750 P4=S6/N
760 PRINT
770 PRINT "STATISTICS USING COHEN METHOD"
780 PRINT
790 PRINT "ADJ. GEOM. MEAN=";EXP(LOG(D0)-(2*P1*P3)/(2*P1†2-P2†2))
800 PRINT "ADJ. STD. DEV. = ";EXP(SQR((P1*P3-P2†2)/(2*P1†2-P2)))
810 PRINT
820 PRINT A$ 
830 GO TO 1100
840 B=1/SQR(2*P1)
850 Z=B*EXP(-0.5*X†2)
860 X9=X*(X>0)-X*(X<0)
870 T9=1/(1+0.33267*X9)
880 P9=1-2*T9*(0.4361836+T9*(-0.1201676+T9*0.937298))
890 P=P9*(1-2*(X>0)/(X<0))
900 H=1/(2/(1-P)-X)
910 H1=H†2*(Z*(Z-X*(1-P))/(1-P);†2-1)*-1
920 F=H*X-H-X-C
930 F1=2*X*H1-X*X*H1-H
940 RETURN
950 N9=1
960 GOSUB 840
970 X=X-F/F1
980 IF ABS(F/F1)/ABS(X)<E THEN 1020
990 IF N9>G THEN 1020
1000 N9=N9+1
1010 GO TO 960
1020 RETURN
1030 PRINT "ENTER NO. OF POINTS TO REMOVE, FOLLOWED BY INDICES OF POINTS"
1040 INPUT R9

```

1045 DELETE M3  
1050 DIM M3(R9)  
1060 FOR J=1 TO R9  
1070 INPUT M3(J)  
1080 NEXT J  
1090 GO TO 370  
1100 END

**BLANK**

**DISTRIBUTION LIST 1**

Names	Copies	Names	Copies
CHEMICAL SYSTEMS LABORATORY			
ATTN: DRDAR-CLB	1	Commander	
ATTN: DRDAR-CLB-C	1	USASED, USAINSOCOM	
ATTN: DRDAR-CLB-PO	1	ATTN: IAFM-SED-III	1
ATTN: DRDAR-CLB-PS	1	Fort Meade, MD 20755	
ATTN: DRDAR-CLB-R	1	DEPARTMENT OF THE ARMY	
ATTN: DRDAR-CLB-T	1		
ATTN: DRDAR-CLS-TE	1	HQDA	
ATTN: DRDAR-CLC-B	1	ATTN: DAMO-NCC	1
ATTN: DRDAR-CLC-C	1	WASH DC 20310	
ATTN: DRDAR-CLC-E	1		
ATTN: DRDAR-CLF	1	HQDA, OCSA	
ATTN: DRDAR-CLJ-R	1	ATTN: DACS-FM (MG R. Anson)	1
ATTN: DRDAR-CLJ-L	2	Room 1A871, Pentagon	
ATTN: DRDAR-CLJ-M	1	Washington, DC 20310	
ATTN: DRDAR-CLJ-P	1		
ATTN: DRDAR-CLN	1	Federal Emergency Management Agency	
ATTN: DRDAR-CLN-S	1	Office of Research/NPP	
ATTN: DRDAR-CLN-ST	1	ATTN: David W. Bensen	1
ATTN: DRDAR-CLN-TE	1	Washington, DC 20472	
ATTN: DRDAR-CLT	1		
ATTN: DRDAR-CLW-C	1	HQ DA	
ATTN: DRDAR-CLW-P	1	Office of the Deputy Chief of Staff for	
ATTN: DRDAR-CLY-A	1	Research, Development & Acquisition	
		ATTN: DAMA-CSS-C	1
		Washington, DC 20310	
AUTHORS COPIES:			
ATTN: DRDAR-CLY-A	11		
RECORD COPY: DRDAR-CLY-A	1	Commander	
DEPARTMENT OF DEFENSE		HQ 7th Medical Command	
Mr. Joseph F. Campbell, Jr.		ATTN: AEMPM	1
Office of Management and Budget/EXOP		APO New York 09403	
New Executive Office Building Rm 10002			
726 Jackson Place, N.W.		Commander	
Washington, DC 20503		DARCOM, STITEUR	
Defense Technical Information Center		ATTN: DRXST-STI	1
ATTN: DTIC-DDA-2	12	Box 48, APO New York 09710	
Cameron Station, Building 5			
Alexandria, VA 22314		Commander	
		USASTCPEO	
		ATTN: MAJ Mikeworth	1
		APO San Francisco 96328	

Commander	Commander
US Army Nuclear & Chemical Agency	US Army Toxic & Hazardous Materials Agency
ATTN: MONA-WE	1
7500 Backlick Rd, Bldg 2073	ATTN: DRXTH-ES
Springfield, VA 22150	ATTN: DRXTH-SE
	ATTN: DRXTH-TE
	Aberdeen Proving Ground, MD 21010
Army Research Office	Commander
ATTN: DRXRO-CB (Dr. R. Ghirardelli)	1
P.O. Box 12211	US Army Foreign Science & Technology Center
Research Triangle Park, NC 27709	ATTN: DRXST-MT3
OFFICE OF THE SURGEON GENERAL	220 Seventh St., NE
Commander	Charlottesville, VA 22901
US Army Medical Bioengineering Research	Director
and Development Laboratory	US Army Materiel Systems Analysis Activity
ATTN: SGRD-UBD-AL, Bldg 568	ATTN: DRXSY-MP
Fort Detrick, Frederick, MD 21701	ATTN: DRXSY-CA (Mr. Metz)
	Aberdeen Proving Ground, MD 21005
Commander	Commander
USA Medical Research Institute of	US Army Missile Command
Chemical Defense	Redstone Scientific Information Center
ATTN: SGRD-UV-L	ATTN: DRSMI-RPR (Documents)
Aberdeen Proving Ground, MD 21010	Redstone Arsenal, AL 35809
US ARMY MATERIEL DEVELOPMENT AND	Director
READINESS COMMAND	DARCOM Field Safety Activity
Commander	ATTN: DRXOS-C
HQ, DARCOM	Charlestown, IN 47111
ATTN: DRCED (BG Robinson)	Commander
5001 Eisenhower Ave	US Army Natick Research and Development
Alexandria, VA 22333	Laboratories
Commander	ATTN: DRDNA-UE (AMEL)
US Army Materiel Development and	ATTN: DRDNA-IC
Readiness Command	ATTN: DRDNA-ICAA
ATTN: DRCLDC	ATTN: DRDNA-IM
ATTN: DRCMT	ATTN: DRDNA-IB
ATTN: DRCSF-P	ATTN: DRDNA-ITF
5001 Eisenhower Ave	Natick, MA 01760
Alexandria, VA 22333	
Project Manager Smoke/Obscurants	
ATTN: DRCPM-SMK	
Aberdeen Proving Ground, MD 21005	1

US ARMY ARMAMENT RESEARCH AND  
DEVELOPMENT COMMAND

Commander  
US Army Armament Research and  
Development Command

ATTN: DRDAR-LCA-L 1  
ATTN: DRDAR-LCE-C 1  
ATTN: DRDAR-LCM-E 1  
ATTN: DRDAR-LCM-SA 1  
ATTN: DRDAR-LCU-CE 1  
ATTN: DRDAR-NC (COL Lyman) 1  
ATTN: DRDAR-SCA-A 1  
ATTN: DRDAR-SCA-C 1  
ATTN: DRDAR-SCA-T 1  
ATTN: DRDAR-SCM 1  
ATTN: DRDAR-SCS 1  
ATTN: DRDAR-TDC (Dr. D. Gyorgy) 1  
ATTN: DRDAR-TSS 2  
ATTN: DRCPM-CAWS-AM 1  
ATTN: DRCPM-CAWS-SI 1  
Dover, NJ 07801

Commander  
ARRADCOM  
ATTN: DRDAR-QAC-E 1  
Aberdeen Proving Ground, MD 21010

Director  
USA Ballistic Research Laboratory  
ARRADCOM  
ATTN: DRDAR-TS8-S 1  
Aberdeen Proving Ground, MD 21005

US Army Armament Research and  
Development Command  
Resident Operations Office  
ATTN: DRDAR-TSE-QA (Robert Thresher) 1  
National Space Technology Laboratories  
NSTL Station, MS 39529

US ARMY ARMAMENT MATERIEL READINESS  
COMMAND

Commander  
US Army Armament Materiel Readiness Command  
ATTN: DRSAR-ASN 1  
ATTN: DRSAR-IRW 1  
ATTN: DRSAR-ISE 1  
ATTN: DRSAR-PE 1  
Rock Island, IL 61299

Commander  
USA ARRCOM  
ATTN: DRSAR-MAY-M 1  
ATTN: DRSAR-MAS-C 1  
ATTN: SARTE 1  
Aberdeen Proving Ground, MD 21010

Commander  
US Army Dugway Proving Ground  
ATTN: Technical Library (Docu Sect) 1  
Dugway, UT 84022

US ARMY TRAINING & DOCTRINE COMMAND

Commandant  
US Army Infantry School  
ATTN: CTDD, CSD, NBC Branch 1  
Fort Benning, GA 31905

Commandant  
US Army Missile & Munitions Center  
and School  
ATTN: ATSK-TME 1  
Redstone Arsenal, AL 35809

Commander  
US Army Logistics Center  
ATTN: ATCL-MC 1  
Fort Lee, VA 23801

Commandant	Project Manager	
US Army Chemical School	Theatre Nuclear Warfare Project Office	
ATTN: ATZN-CM-C	1 ATTN: TN-09C	1
ATTN: ATZN-CM-AD	2 Navy Department	
ATTN: ATZN-CM-TPC	2 Washington, DC 20360	
Fort McClellan, AL 36205		
Commander	Chief of Naval Research	
USAAVNC	ATTN: Code 441	1
ATTN: ATZQ-D-MS	800 N. Quincy Street	
Fort Rucker, AL 36362	1 Arlington, VA 22217	
Commander	Commander	
US Army Infantry Center	Naval Facilities Command	
ATTN: ATSH-CD-MS-C	1 ATTN: FAC-032	1
Fort Benning, GA 31905	1 ATTN: FAC-062	1
	200 Stovall St	
	Alexandria, VA 22332	
Commander	Commander	
US Army Infantry Center	Naval Surface Weapons Center	
DIRECTORATE OF PLANS & TRAINING	1 Code G51	1
ATTN: ATZB-DPT-PO-NBC	Dahlgren, VA 22448	
Fort Benning, GA 31905		
Commander	Commanding Officer	
USA TRAINING AND DOCTRINE COMMAND	Naval Weapons Support Center	
ATTN: ATCD-N	1 Applied Sciences Department	
Fort Monroe, VA 23651	ATTN: Code 50C, Bldg 190	1
	Crane, IN 47522	
Commander	Commander	
US Army Armor Center	Naval Air Development Center	
ATTN: ATZK-CD-MS	1 ATTN: Code 2012 (Dr. Robert Helmbold)	1
ATTN: ATZK-DPT-PO-C	Warminster, PA 18974	
Fort Knox, KY 40121		
US ARMY TEST & EVALUATION COMMAND	US MARINE CORPS	
Commander	Commanding General	
US Army Test & Evaluation Command	Marine Corps Development and	
ATTN: DRSTE-CM-F	1 Education Command	
Aberdeen Proving Ground, MD 21005	ATTN: Fire Power Division, D091	1
	Quantico, VA 22134	
DEPARTMENT OF THE NAVY	DEPARTMENT OF THE AIR FORCE	
Chief, Bureau of Medicine & Surgery	Department of the Air Force	
Department of the Navy	Headquarters Foreign Technology Division	
ATTN: MED 3C33	1 ATTN: TQTR	1
Washington, DC 20372	Wright-Patterson AFB, OH 45433	

AMD/RDTK			
HQ FTD/NIIS Wright-Patterson AFB, OH 45433	1	ATTN: LTC T. Kingery Brooks AFB, TX 78235	1
ASD/AESD Wright-Patterson AFB, OH 45433	1	OUTSIDE AGENCIES	
AFAMRL/HE ATTN: Dr. Clyde Replogle Wright-Patterson AFB, OH 45433	1	Battelle, Columbus Laboratories ATTN: TACTEC 505 King Avenue Columbus, OH 43201	1
AFAMRL/TS ATTN: COL Johnson Wright-Patterson AFB, OH 45433	1	Toxicology Information Center, JH 652 National Research Council 2101 Constitution Ave., NW Washington, DC 20418	1
HQ AFSC/SD2 ATTN: CPT D. Riediger Andrews AFB, MD 20334	1	US Public Health Service Center for Disease Control ATTN: Lewis Webb, Jr.	1
HQ, AFSC/SDNE Andrews AFB, MD 20334	1	Building 4, Room 232 Atlanta, GA 30333	
HQ, AFSC/SGB Andrews AFB, DC 20334	1	Director Central Intelligence Agency ATTN: AMR/ORD/DD/S&T	1
HQ, NORAD ATTN: J-3TU Peterson AFB, CO 80914	1	Washington, DC 20505	
ADDITIONAL ADDRESSEES			
USAF TAWC/THL Eglin AFB, FL 32542	1	Commandant Academy of Health Sciences, US Army	1
AFATL/DLV Eglin AFB, FL 32542	1	ATTN: HSHA-CDH ATTN: HSHA-IPM Fort Sam Houston, TX 78234	2
USAF SC ATTN: AD/YQ ATTN: AD/YQO (MAJ Owens) Eglin AFB, FL 32542	1	Commander 217th Chemical Detachment	1
AD/XRO Eglin AFB, FL 32542	1	ATTN: AFVL-CD Fort Knox, KY 40121	
USAFSAM/VN Deputy for Chemical Defense ATTN: Dr. F. Wesley Baumgardner Brooks AFB, TX 78235	1	Headquarters US Army Medical Research and Development Command ATTN: SGRD-RMS Fort Detrick, MD 21701	1

Commander  
US Army Environmental Hygiene Agency  
ATTN: Librarian, Bldg 2100 1  
Aberdeen Proving Ground, MD 21010

Stimson Library (Documents) 1  
Academy of Health Sciences, US Army  
Bldg. 2840  
Fort Sam Houston, TX 78234